

**Environmental Public Health Department**  
In Cooperation with Missouri Department of Health and Senior Services

Grundy County Health Department  
1716 Lincoln  
Trenton, MO 64683  
PH: 660-359-4196  
Fax: 660-359-5470

Livingston County Health Center  
800 Adam Drive, P.O. Box 973  
Chillicothe, MO 64601  
PH: 660-646-5506  
Fax: 660-646-4485

September 2008

**Thermolabel**

The waterproof Thermolabel is directly applied to a ceramic plate during the entire wash and rinse cycles in the dishwasher. This is the last check of the proper sanitization, reflecting the true temperature of the ceramic plate itself during the final rinse cycle. When the actual plate temperature reaches or exceeds the sanitization point of 160°F, the Thermolabel responds with a sharply defined color change from white to black. This color change is irreversible. The used label can then be attached to the Record Keeping Log as irrefutable evidence of compliance with the food safety assurance procedures.

**THERMOLABEL**  
Temperature Indicating Labels

160° F      71° C

144 labels/pkg.

Peel and attach label to a clean, dry surface.  
The label will turn black within a few seconds  
when the rated temperature is reached or  
exceeded. This color change is irreversible.



**DeltaTRAK, Inc.**

P.O. Box 398, Pleasanton, CA. 94566 USA  
Phone: (925)249-2250 Fax: (925)249-2251